

Accsense Ethernet Pro User Manual



Terry Nagy

CAS DataLoggers

10/22/2025

Rev 0.1

TABLE OF CONTENTS

TABLE OF CONTENTS	2
SAFETY ALERTS	6
INTRODUCTION	7
SENSORS AND INPUT SIGNALS	7
ANALOG INPUTS	8
MEASUREMENT AND INDICATION OF INPUT TYPES	9
DIGITAL INPUT	13
DIGITAL OUTPUT	13
POWER, SENSOR AND SIGNAL CONNECTIONS	14
ELECTRICAL CONNECTIONS	14
POWER SUPPLY	15
ANALOG INPUTS	15
DIGITAL OUTPUT	18
DIGITAL INPUT	19
MECHANICAL INSTALLATION	20
DIMENSIONS	23
COMMUNICATIONS INTERFACES	24
USB	24
Ethernet	25
DISPLAY AND NAVIGATION	26
DISPLAY INFORMATION	26
OPERATION KEYS	27
NAVIGATION SCREENS	28
CONFIGURATION SOFTWARE	34




NXPERIENCE.....	34
CONFIGURING ACCSENSE ETHERNET PRO WITH NXPERIENCE	34
GENERAL PARAMETERS.....	34
ANALOG CHANNELS PARAMETERS.....	36
DIGITAL CHANNEL PARAMETERS.....	38
CHANNELS GENERAL PARAMETERS	39
LOG CONFIGURATION	40
COMMUNICATION PARAMETERS.....	42
ALARM CONFIGURATION	44
DIAGNOSTICS.....	46
LOGS	46
CHANNELS	47
ALARMS	48
COMMUNICATION.....	48
MISCELLANEOUS	49
ACCSENSE CLOUD WEB SOFTWARE	50
CONNECTION TO ACCSENSE CLOUD PORTAL.....	50
USING A WEB BROWSER	50
MOBILE APP.....	50
ACCOUNTS PREFERENCES – DESKTOP ONLY	51
GENERAL INFORMATION.....	51
VISUALIZATION PREFERENCES.....	52
SECURITY PREFERENCES.....	53
USERS.....	53
SENSOR SUMMARY	56
ALARM LIST.....	56

SENSOR LIST.....	57
DEVICES	60
AUDIT LOG.....	63
NOTIFICATION LOG.....	63
ALARM LOG	64
USER LOG.....	64
CONFIGURATION LOG	65
APPENDIX A - TROUBLESHOOTING.....	66
START/STOP MODES.....	66
CLOCK	66
ALARM INFORMATION	66
ANALOG INPUTS	66
UNREGISTERED ALARMS	67
COMMUNICATION LINK LOSS.....	67
PROBLEMS COMMUNICATING WITH THE DEVICE VIA USB INTERFACE	67
PROBLEMS DURING FIRMWARE UPDATE VIA USB INTERFACE.....	68
APPENDIX B – UPDATING FIRMWARE.....	71
FIRMWARE UPDATE VIA USB	71
OVER THE AIR (OTA) FIRMWARE UPDATE.....	71
APPENDIX C - TECHNICAL SPECIFICATIONS	72
SENSORS RANGE AND ACCURACY	73
ETHERNET CONNECTIVITY	76
APPENDIX D - CERTIFICATIONS.....	77
FCC.....	77
IC.....	77
CE Mark / UKCA	77

ANATEL	77
NORM CISPR 22	78
APPENDIX E - WARRANTY.....	79

SAFETY ALERTS

The symbols below are used throughout this manual to draw the user's attention to important information regarding safety and use of the device.

		
CAUTION Read the manual fully before installing and operating the device.	CAUTION OR HAZARD Risk of electric shock.	ATTENTION Material sensitive to static charge. Check precautions before handling.

Safety recommendations should be observed to ensure user safety and to prevent damage to the device or system. If the device is used in a manner other than that specified in this manual, the safety protections may not be effective.

INTRODUCTION

Accsense Ethernet Pro is an electronic wireless data register, also known as a *data logger*, which comprises three analog sensors inputs and one digital sensor input, respectively called the "analog measuring channel" and the "digital measuring channel". With a memory capacity for up to 140,000 logs, it allows the use of batteries, to keep its autonomy and continue to log data even during external power outages. It features a large display that offers a comfortable view of measured variables and general device information. Furthermore, the device's enclosure has a protection cover for the connections, a sealing ring and a holder that allows its attachment to a wall or metal surface by means of the optional bracket with magnetic inserts.

The analog inputs accept any type of temperature sensor, such as thermocouples, Pt100 or sensors for any other quantities with current or voltage signals. The digital channel can log the time of events, such as opening a door, or counting pulses from a flow sensor. **Accsense Ethernet Pro** also has the following internal sensors: temperature, battery voltage, and external power supply voltage, which can also log the values in the memory, taking the place of any of the available measurement channels. Its wide display allows you to view up to three variables simultaneously, and displays indications such as alarms, communication status, enabled channels, battery voltage level, among other information.

All device configurations can be accessed by user via desktop or notebook connected to **Accsense Ethernet Pro** USB interface. **CAS DataLoggers** provides the **Accsense NXperience** software on the website download area: <https://dataloggerinc.com/downloads/accsense-monitoring-systems/>

SENSORS AND INPUT SIGNALS

Accsense Ethernet Pro allows users to choose, in addition to the channels to be registered and sensor types, configuration that provides flexibility to accommodate many applications. In addition, is possible to configure the device with the following parameters:

- **Log Range:** Shows frequency, in seconds, with which an acquisition must be made and logged in the memory. A low periodicity will increase battery consumption and fill up the memory faster.
 - **Minimum Range:**
 - 1 second (if no channel is configured to operate on average)
 - 10 seconds (if a channel is configured to operate on average)
 - **Maximum Range:** 18 hours.
- **Display Update Range:** Shows frequency, in seconds, with which an acquisition must be made and updated on the display. It allows you to save memory by configuring it to a larger range of logs without damaging the Display update rate. Low frequency increases battery consumption. This range can be disabled if set to '0'. Thus, the display update will take place in the log range.
 - **Minimum Range:** 1 second
 - **Maximum Range:** 1 hour

When configuring a Display Update Range, it should be less than the Log Range. Otherwise, it will be ignored, and the display will be updated at the same Log Range.

The Display Update Range only updates Analog Channels that are not configured to operate on average. Thus, the Digital Channel that is configured to operate in counting mode and the Analog Channels that are configured to operate on average will only have their information updated at each log range.

If the digital channel is operating in the "Event Log" mode, each event will update its respective information on the display.

ANALOG INPUTS

Accsense Ethernet Pro has three channels for reading analog signals. The types of signals and sensors accepted by them are:

- **Temperature Sensors:**
 - RTD, Pt100
 - Thermocouples J, K, T, N, E, R, S, and B
 - Internal Temperature Sensor
- **Linear Sensors:**
 - 0 to 50 mV
 - 0 to 5 V
 - 0 to 10 V
 - 0 to 20 mA
 - 4 to 20 mA
- **Internal Diagnostic Sensors:**
 - Battery Voltage
 - External Power Supply Voltage

Each type has specific operation configurations and characteristics. Its configurations and characteristics are described below:

- **Temperature Sensors:**
 - Inform the measured temperature within the possible measuring range of each sensor.
 - The maximum resolution for the Temperature Sensors is 0.1 °C.
 - You can configure them to be displayed with one or no decimal places.
 - You can configure them to be displayed in units of measure °C or °F.
- **Linear Sensors:**
 - Displays the value within the range required by the user (defined by the parameter "User Range"), as configured in the "Lower Limit", "Upper Limit", and "Number of Decimal Places" parameters.
 - **Number of Decimal Places:** Allows you to choose to use 0, 1, or 2 decimal places.

- **Lower Limit:** Corresponds to the value configured to represent the minimum value of the chosen sensor:
 - Minimum -19999 to 0 decimal places
 - Minimum -1999.9 to 1 decimal place
 - Minimum -199.99 to 2 decimal places
- **Upper Limit:** Corresponds to the value configured to represent the maximum value of the chosen sensor:
 - Maximum 19999 to 0 decimal places
 - Maximum 1999.9 to 1 decimal place
 - Maximum 199.99 to 2 decimal places
- You can configure them to be displayed in units of measurement °C, °F or in a custom unit of up to 8 characters, which will not show on the display.
- The maximum resolution for linear sensors corresponds to a ratio between the user range and the maximum resolution of the chosen sensor.
- **Internal Diagnostic Sensors:**
 - Displays the voltage of the possible **Accsense Ethernet Pro** power supply sources.
 - The maximum resolution for the internal diagnostic sensors is 0.01 V.
 - You can configure them to be displayed with 0, 1, or 2 decimal places.
 - The unit of measure for these sensors is Volts and no unit symbol is displayed.

Refer to the [Technical Specifications](#) chapter to check these signals' accuracy. Refer to the [Installation](#) chapter to check these signals' connection.

An analog/digital (A/D) converter with high resolution and accuracy is used to read the sensors connected to the analog channel inputs. In the desired scan range, all the analog channels enabled will be read.

Each type of input signal has a valid measuring range (see the chapter [Technical Specifications](#)). However, the device can typically measure signals which slightly exceed the limits of this range. The amount it can measure beyond it, however, depends on the type of input configured and can vary between different devices.

The following table describes the input types supported by the device, the device's signal conditions and their respective indications.

MEASUREMENT AND INDICATION OF INPUT TYPES

INPUT TYPE	INPUT SIGNAL CONDITION	INDICATION
Pt100	Within range	Read input value
	Pt100 with one or more wires disconnected	---- will be displayed -22000 will be logged in the memory

INPUT TYPE	INPUT SIGNAL CONDITION	INDICATION
	Slightly above the upper limit	Read input value *
	Slightly below the lower limit	Read input value *
	Far above the upper limit	UUUU will be displayed 32767 will be logged in the memory
	Far below the lower limit	NNNN will be displayed -32000 will be logged in the memory
Thermocouples J, K, T, E, N, R, S and B	Within range	Read input value
	Open Thermocouple	---- will be displayed -22000 will be logged in the memory
	Slightly above the upper limit	Read input value *
	Slightly below the lower limit	Read input value *
	Far above the upper limit	UUUU will be displayed 32767 will be logged in the memory
	Far below the upper limit	NNNN will be displayed -32000 will be logged in the memory
Voltage 0 to 50 mV	Within range	Read input value converted into User
	Signal disconnected	---- will be displayed -22000 will be logged in the memory
	Slightly above the upper limit	Read input value converted into User Range *
	Slightly below the lower limit	Read input value converted into User Range *
	Far above the upper limit	UUUU will be displayed 32767 will be logged in the memory
	Far below the lower limit	NNNN will be displayed -32000 will be logged in the memory
Voltage 0 to 5 V 0 to 10 V	Within range	Read input value
	Signal disconnected	0 V converted into User Range
	Slightly above the upper limit	Read input value converted into User Range *
	Slightly below the lower limit	Read input value converted into User Range *
	Far above the upper limit	UUUU will be displayed 32767 will be logged in the memory

INPUT TYPE	INPUT SIGNAL CONDITION	INDICATION	
	Far below the lower limit	nnnn will be displayed -32000 will be logged in the memory	
Current 0 to 20 mA 4 to 20 mA	Within range	Read input value converted into User Range	
	Signal disconnected	0 a 20 mA	0 mA converted into User Range
		4 a 20 mA	---- will be displayed -22000 will be logged in the memory
	Slightly above the upper limit	Read input value converted into User Range *	
	Slightly below the lower limit	0 a 20 mA	It is not possible to decrease more than the lower limit
		4 a 20 mA	Read input value converted into User Range *
	Far above the upper limit	uuuu will be displayed 32767 will be logged in the memory	
	Far below the lower limit	0 a 20 mA	It is not possible to decrease more than the lower limit
4 a 20 mA		nnnn will be displayed -32000 will be logged in the memory	


(*) Note: The analog channel indication continues slightly beyond the limits specified for the selected input type. However, in this condition, accuracy is not guaranteed.

Table 1 – Measurement and indication of input types by **Accsense Ethernet Pro**

Accsense Ethernet Pro allows you to configure settings to be applied to analog sensor readings. These settings can be used to correct errors in the sensor or process in which the sensor is installed and applied individually for each analog channel. Two adjustment modes are provided by the device:

- **Offset:** Allows each analog channel to choose an Offset value to be added to the channel reading indication. It is a simple and fast feature to adjust the display throughout the range.
- **Custom Calibration:** Allows you to enter up to 10 set points for each channel to correct distortions in reading these channels at these points. We call this characteristic a "custom calibration" because it allows the user to adjust the indication at the desired points by zeroing their errors. The adjustment is made linearly between the points entered, according to the values entered.

It is important to note that both the Offset adjustment and the insertion of custom calibration points are optional, only indicated for those who wish to adjust the indication to a local standard, since the **Accsense Ethernet Pro** has already been calibrated at the factory.

	<p>Whenever you change the input type, make sure that the custom calibration points of the previous input are deleted!</p>
---	---

For each analog channel, a unique (Tag) name must be assigned, which will be used to reference the channel. You should also choose the type of input (sensor) that will be connected to that channel. In addition to that, you can assign the unit of measured value: for temperature sensors (Pt100 or thermocouples), degrees Celsius (°C) or Fahrenheit (°F); for linear sensors (current or voltage), you can enter the desired unit.

In the case of linear input types, one must choose the sensor indication range, that is, what the channel should indicate when the input is at its minimum value and what it should indicate when it is at its maximum value (minimum and maximum values considering the **Accsense Ethernet Pro** working range for the chosen input type). Once the 4 to 20 mA input type is chosen, for example, a pressure transmitter from 0 to 2 bars will be connected. In this case, "0.0" must be chosen as the minimum value and "2.0" as the maximum value in the input configuration. All resolution and accuracy available will be contained within the chosen range.

When a simulator is used on analog inputs that are connected to the mains (e.g. a thermocouple or voltage simulator) and it is not isolated, it is recommended to use a different reading interface than USB. In some cases, it is possible to observe noise and measurement created by the influence of the USB cable connection, potential by ground loops.

The **Accsense Ethernet Pro**, when operated by batteries, keeps the entire analog circuit switched off while no acquisition is being made. This strategy is necessary so that it can operate for more than two years without needing to change batteries. This characteristic may cause some undesirable effects during calibration, as some analog signal simulators (e.g., thermocouples simulator or a Pt100) may not operate properly, causing false reading offsets and oscillations. Should such a problem be identified, it is recommended to power the **Accsense Ethernet Pro** by external source while using a simulator.

Setting the local network frequency (50 Hz or 60 Hz) is important as it helps improve the performance of reading analog channels even while the device is running on battery power. Usually, the power grid causes interference in the signal read from the sensors, which can be more easily mitigated if the correct frequency filtering is applied.

DIGITAL INPUT

Accsense Ethernet Pro has a Digital Input channel that can be configured for "Pulse Count", "Event Log", or even for "Logs Control" modes. This Digital Input can be disabled.

Regardless of the function for which it will be used, you must configure the type of sensor output that will be connected to the input: PNP, NPN, or Dry Contact (refer to chapter [Installation](#) to see how the sensors should be connected). In addition to that, it is necessary to select the edge of interest of the digital signal to generate the count, event, or start/end of logs: rising edge, falling edge, or both edges.

Relationship between Sensor Type, Sensor Status, and Logical Level obtained in Accsense Ethernet Pro		
Sensor Type	Sensor State	Logical Level
PNP	Open	0
	Closed	1
NPN	Open	1
	Closed	0
Dry Contact	Open	1
	Closed	0

Table 2 – Digital Input

For Dry Contact sensors, it is necessary to set a *debounce* time of at least 50 ms (sensor stabilization time / time in which the sensor must remain in the state of interest for it to be considered valid). For PNP or NPN type sensors, if configured in "Pulse Count" mode, it is not necessary to set a *debounce* time. However, if the digital input is configured for the "Event Log" or "Logs Control" modes, a minimum *debounce* of 50 ms is required to prevent any noise from generating a false event. In the "Event Log" and "Logs Control" modes, events will be generated after the end of the *debounce* time.

DIGITAL OUTPUT

The **Accsense Ethernet Pro** has a PNP-type Digital Output which when triggered places the voltage from the external power supply to the respective terminal and can be disabled or configured to operate in one of the modes described below:

- **Auxiliary Electronic Switch:** Allows you to control the power supply of external instruments during analog channel readings. 4-20 mA transmitters, for example, can be fed by the digital output pin, so that they are only turned on when they are read – which would save energy from the **Accsense Ethernet Pro** external power supply, which can be a 12 V battery. In the "Auxiliary Electronic Switch" mode, it will be necessary to configure how long before each acquisition the digital output must be triggered.
 - **Drive Time:** It defines, in seconds, how long before each acquisition the digital output must be triggered. It will be deactivated when the acquisition is ready. Such time cannot be longer than the lowest acquisition range (Instant, Average = 1/10 of the snapshot, Interval of Display Range). If equal to 0, the Auxiliary

Electronic Switch will be enabled at the exact moment of an acquisition. If greater than or equal to the lowest acquisition range, the Auxiliary Electronic Switch will remain be enabled.

- **Alarm Status:** Allows you to follow the current general alarm status. If any channel is in an alarm situation, the Digital Output will be triggered. If no channel is set to alarm, the Digital Output will be disabled.

POWER, SENSOR AND SIGNAL CONNECTIONS

ELECTRICAL CONNECTIONS

Accsense Ethernet Pro has 4 detachable connection terminal blocks for connection of external power supply, digital output load, digital input sensor, and analog sensors for each of the 3 available analog channels. Figure below illustrates electrical connections in a basic way:




Figure 1 – Electrical connections


For the sensors connection, it is recommended that the connection terminal blocks be previously detached from the device. To streamline the sensors connection, it is necessary to use the enumeration printed on the connectors and the Electrical Connections image in the figure above, and in the Connections' Protection Cover.



The power supply, digital output, digital input, and analog inputs terminals are not isolated from each other!


Therefore, analog, and digital signals from the same voltage source must not be used, otherwise the device will malfunction.

POWER SUPPLY




ANALOG INPUTS


PT100 CONNECTION




THERMOCOUPLE CONNECTION




VOLTAGE CONNECTION (MV)



CURRENT CONNECTION (MA)



VOLTAGE CONNECTION (V)



EXAMPLE OF CONNECTION OF 4-20 MA TRANSMITTERS POWERED BY THE CURRENT LOOP





Figure 2 – Example of connecting transmitters that are fed by the loop

DIGITAL OUTPUT

ALARM STATUS MODE CONNECTION



CONNECTION IN "AUXILIARY ELECTRONIC SWITCH" MODE

The connection to the Digital Output in the "Auxiliary Electronic Switch" mode, used to power current transmitters, is made at the terminals according to the figure on the side. To use the Digital Output, you must power the device with an external power supply. The source used must be able to provide current compatible with the number of transmitters used.





Figure 3 – Connection in "Auxiliary Electronic Switch" Mode


DIGITAL INPUT

PNP CONNECTION


Sensor



NPN CONNECTION



DRY CONTACT CONNECTION



MECHANICAL INSTALLATION

Accsense Ethernet Pro has a high-quality casing, built in ABS + PC and with IP40 protection index.

To streamline the **Accsense Ethernet Pro** attachment, the device comes with a mounting bracket designed for wall mounting, which has three oblong holes, arranged in a triangle, made to fix it using screws. Optionally, to facilitate the fixation on metal surfaces, it is possible to purchase the device model that comes with a fixing bracket with magnetic inserts.

To assist in the installation aesthetics, two openings in the lower part of the fixing bracket can be used to pass the sensors that are connected to the device. In addition to that, this bracket has a ring that allows the placement of a padlock preventing **Accsense Ethernet Pro** from being removed from the installation location.

With the help of two screwdrivers and through two lateral fittings, it is possible to fix or remove the **Accsense Ethernet Pro** from the bracket.




Figure 4 – Mounting bracket

To improve the device installation aesthetics, the **Accsense Ethernet Pro** comes with a protection cover for the connections, which is lockable in the bottom of the device and that hides its sensors. This protection cover has four detachable cavities to facilitate sensor installation.




Figure 5 – Connections' Protection Cover




Figure 6 – Dimensions of protection cover detachable connections and cavities

To detach the protection cover, you must press the sides, one side at a time.



Figure 7 – Removing the protection cover

To attach the protection cover, it is necessary to press the area designated by the arrows and push one side at a time from the outside.




Figure 8 – Fitting the protection cover

DIMENSIONS

Figure 9 – Accsense Ethernet Pro dimensions

To open the battery compartment, press the cover in the arrows region and push it in from the inside out.






Figure 10 – Batteries cover

COMMUNICATIONS INTERFACES

USB

The USB interface is the preferred interface for configuring, monitoring, and downloading device logs. It is the only interface which can never be disabled. To access it, you must install **NXperience** for Windows. This way, the USB driver will be installed (see chapter [NXperience](#)). A standard micro-USB cable must be used for desktop or notebook connection.

When connecting the USB cable, the respective icon should light up on the device's display, indicating that its interface is ready for use. On first use, you must wait for Windows to automatically install the driver already preinstalled by **NXperience**. The device's configuration, monitoring and data download, made through the USB interface, must be performed by **NXperience**.

 	<p>The USB interface is NOT isolated.</p> <p>Its purpose is temporary use during CONFIGURATION, MONITORING, and LOG DOWNLOAD. For the safety of people and devices, it should only be used when the device is disconnected from the external power supply.</p> <p>It is possible to use the USB interface in any other connection condition, although the decision requires a careful analysis by the person in charge of installation.</p>
---	--






Figure 11 – USB cable connection

Ethernet

Accsense Ethernet Pro has an 802.3 10/100Mb interface with a standard RJ-45 connector for sending registered data through protocols compatible with the device. The Ethernet interface also sends the **Accsense Ethernet Pro** configuration parameters of the through these same protocols.

If the Ethernet interface is enabled and the device is connected to the network, the  symbol will remain lit. While data is being sent through this interface, the symbol  will remain lit.



While the Accsense Ethernet Pro is operating on batteries and to reduce power consumption, the Ethernet interface will remain disabled. All other features of the device, however, remain operable for at least 80 hours.

When power from the power supply is restored, the Ethernet interface will be activated, and the data recorded in memory during the power interruption will be published.

DISPLAY AND NAVIGATION



DISPLAY INFORMATION






Accsense Ethernet Pro has an LCD display with 3 numerical lines of 4 ½ digits, to display the current value of all enabled channels, as well as the minimum and maximum values thereof. At the same time, it is possible to display the current value of up to three analog channels and, in a second screen, if enabled, the digital input current value. In addition to channel information, **Accsense Ethernet Pro** has 7 screens with a variety of information and features and 24 symbols that allow for easy information visualization and diagnostics.

See below an illustration of the display with a description of each symbol's functionality.





Figure 12 – Accsense Ethernet Pro Display Information

- : It remains lit while **Accsense Ethernet Pro** has a valid IP on the wireless network to which you are connected. If the device is set to wake up by keyboard, it will remain on while the interface remains available.
- : When the digital channel is disabled, it remains off. When set to "Pulse Count" mode, it will remain on. When set in the "Event Log" or "Logs Control" modes, it will remain lit, flashing when an event is detected at the digital input.
- **USB**: Lights up when the USB cable is connected. Turns off when the USB cable is disconnected.
- **LOG**: It remains lit from the moment the device registers the first log until the moment it stops logging. When set to "Daily" mode, which must start and end daily at a predetermined time, it will remain lit within the set time. It will flash while logging, turn off at the time of a log and restart.
- **ALM**: Lights up and stays on when entering an alarm condition. Turns off when a new configuration is received, or the alarm status is cleared. Indicates to the user that, at some point, an alarm has been triggered.

- **1, 2, 3, 4**: Light up while the alarm conditions of the corresponding channels are satisfied: 1 (analog channel 1), 2 (analog channel 2), 3 (analog channel 3) and 4 (digital channel). When you exit the alarm condition, the flag will be cleared.
- : Indicates the battery voltage level. This symbol is updated next to the log range (even if the device is not logging), with a minimum of 5 minutes. Thus, if the device is configured to log every 1 second, the battery indicator will refresh every 5 minutes. If the logging interval is longer than 5 minutes, the battery indicator will update with the same log range.
 - : Battery over 75 %
 - : Battery over 50 %
 - : Battery over 25 %
 - : Battery below 25 % (provide battery replacement)
- **MAX**: Lights up while the "Maximum" values information reached in each channel are being displayed.
- **COM**: Flashes to inform the receipt of valid data packet from one of the available communication interfaces.
- **CH1, CH2, CH3, CH4**: Indicates which channels are enabled.
- **MIN**: Lights up while the "Minimum" amount of information is being displayed.
- **°F, °C**: If the channel unit is set to °F or °C, one of the symbols will light up during channel display. Otherwise, no unit symbol will be displayed.
- **PM**: If the clock is set in the 12-hour format, the PM symbol will light up when the clock is displayed, and the time is later than 1 pm.



OPERATION KEYS

To navigate between the screens, **Accsense Ethernet Pro** has 2 keys:  . Each key, depending on the current navigation screen, has two or more features:

- Short touch (less than 2 seconds):
 - Proceeds to the next screen if the current screen mnemonic is being displayed.
 - Displays the mnemonic of the current screen again if the screen information is being displayed.
- Long touch (longer than 2 seconds or held down):
 - Takes an action within the current screen.
- Both keys held down (longer than 2 seconds or held down):
 - Takes a second action within the current screen.













If the buzzer is active, pressing any key will mute it.







NAVIGATION SCREENS


















To streamline information identification on each screen, a mnemonic, which will remain visible for two seconds, will be displayed when pressing a key. If no key is pressed for this period, the information on the current screen will be displayed. If the  key or the  key is pressed while a mnemonic is being displayed, the device will advance to the next screen or return to the previous one, which will be properly specified by their mnemonics.
















When the device is displaying the information on a screen, simply press any of the two keys to make the mnemonic appear again. To access the desired screen, just wait two seconds.













The table below shows all screens, mnemonics, and information about them, the description of each information and keys function of each screen available in the device.
















SCREEN	MNEMONIC	INFORMATION	DESCRIPTION	KEYS FUNCTION
1. Analog Inputs	 <p>Displayed for 2 seconds before accessing the "Analog Inputs" screen.</p>	 <p>This screen will be updated by the log range and/or by the display update.</p>	<p>Displays the current value of the analog channels and allows the display of the maximum and minimum values reached by each channel.</p> <p>Line 1: Analog channel 1 value. Line 2: Analog channel 2 value. Line 3: Analog channel 3 value.</p>	 Key held down or long touch: Informs the maximum value reached in each analog channel.
				 Key held down or long touch: Informs the minimum value reached in each analog channel.
				  Both keys held down: Clears the alarm statuses and the minimum and maximum values reached by each analog channel.
2. Digital Input Pulse Count: Flow Rate	 <p>Displayed for 2 seconds before moving to analog inputs – Pulse Count: Flow Rate screen.</p>	 <p>This screen is updated by the display update interval.</p>	<p>When enabled and configured in "Pulse Count" mode and then configured with the "Average Flow by Acquisition Interval" option (Application parameter / Flow Rate function), it displays the average flow logged within the configured log interval. If it is not configured, this screen will not be displayed.</p> <p>Use the three lines of the display to display the logged flow rate.</p>	 Key held down or long touch: Informs the maximum flow rate.
				 Key held down or long touch: Informs the minimum flow rate.
				  Both keys held down: Clears the minimum and maximum values reached by each channel.

SCREEN	MNEMONIC	INFORMATION	DESCRIPTION	KEYS FUNCTION
<p>3. Digital Input Pulse Count: Count</p>	 <p>Displayed for 2 seconds before moving to digital input screen – Pulse Count: Count.</p>	 <p>This screen is updated by the display update interval.</p>	<p>When enabled and configured in the "Pulse Count" mode and then configured with "Acquisition Interval Counting" option (Application parameter / Count function), it displays the registered count within the configured registered acquisition interval. If it is not configured, this screen will not be displayed.</p> <p>Uses the three lines of the display to display the logged count.</p>	<p> Key held down or long touch: Informs the maximum count rate.</p> <p> Key held down or long touch: Informs the minimum count rate.</p> <p>  Both keys held down: Clears the minimum and maximum values reached by each channel.</p>

SCREEN	MNEMONIC	INFORMATION	DESCRIPTION	KEYS FUNCTION
4. Digital Input Pulse Count: Accumulator	 <p>Displayed for 2 seconds before moving to digital input screen – Pulse Count: Accumulator.</p>	 <p>This screen is updated by the display update interval.</p>	<p>When enabled and configured in the "Pulse Count" mode and then set to "Volume since Last Reset" (Application parameter / Flow Rate function) or the option "Accumulated Count Since Last Reset" (Application parameter / Count function), displays the volume or count accumulated since the last digital channel reset. If it is not configured, this screen will not be displayed.</p> <p>Uses the three lines of the display to display the accumulated volume or count.</p>	 Key held down or long touch: No action.
				 Key held down or long touch: No action.
				 Both keys held down: No action.
5. Digital Input Event Log or Logs Control	 <p>Displayed for 2 seconds before accessing the digital input screen – Event Log or Logs Control.</p>	 <p>This screen is updated every time an event is detected in the digital input.</p>	<p>When enabled and configured in "Event Log" or "Logs Control" modes, it displays the last event detected at the digital input.</p> <p>Line 1: Edge detected in the event: 0 – Falling edge 1 – Rising edge</p> <p>Line 2: Day. Month of the event (if the 24-hour format is selected); Month. Day of the event (if the AM/PM format is selected).</p> <p>Line 3: Hour: Minute of the event.</p>	 Key held down or long touch: No action.
				 Key held down or long touch: No action.
				 Both keys held down: No action.
				 Key held down or long touch: Informs the minimum value reached.
				 Both keys held down: Clears the minimum and maximum values reached.
6. Internal Temperature	 <p>Displayer for two seconds before accessing the "Internal Temperature" screen.</p>	 <p>This screen will be updated with information about the internal temperature of the device.</p>	<p>Displays the internal temperature of the device.</p>	 Key held down or long touch: Informs the maximum value reached.
				 Key held down or long touch: Informs the minimum value reached.
				 Both keys held down: Clears the minimum and maximum values reached.

SCREEN	MNEMONIC	INFORMATION	DESCRIPTION	KEYS FUNCTION
7. Log Memory	 <p>Displayed for two seconds before accessing the "Log Memory" screen.</p>	 <p>This screen will be updated by the logs range.</p>	<p>Displays the number of logs in the memory and free memory percentage.</p> <p>Line 1 and 2: Number of logs recorded in the memory.</p> <p>Line 3: Free memory percentage.</p>	<p> Key held down or long touch: No action.</p> <p> Key held down or long touch: No action.</p> <p>  Both keys held down: No action.</p>
8. Date/Time	 <p>Displayed for two seconds before accessing the "Date/Time" screen.</p>	 <p>This screen will be updated by the log range and/or by the display update.</p>	<p>Displays the device's current date and time.</p> <p>Line 1: Year.</p> <p>Line 2: Month.Day.</p> <p>Line 3: Hour:Minute.</p>	<p> Key held down or long touch: No action.</p> <p> Key held down or long touch: No action.</p> <p>  Both keys held down: No action.</p> <p> Key held down or long touch: No action.</p> <p>  Both keys held down: No action.</p>

SCREEN	MNEMONIC	INFORMATION	DESCRIPTION	KEYS FUNCTION
<p>9. Firmware Version</p>	 <p>Displayed for two seconds before accessing the "Firmware Version" screen.</p>	 <p>This screen will display the device and Ethernet module firmware versions.</p>	<p>Displays the device and Ethernet module firmware versions.</p> <p>Line 2: Firmware version of the device.</p> <p>Line 3: Ethernet module firmware version.</p>	<p> Key held down or long touch: Increases contrast (maximum of 7).</p> <p> Key held down or long touch: Decreases contrast (minimum of 0).</p> <p>  Both keys held down: No action.</p>
<p>10. Display Contrast Adjustment</p>	 <p>Displayed for two seconds before accessing the "Display Contrast Adjustment" screen.</p>	 <p>This screen will be updated whenever the display contrast is adjusted.</p>	<p>Displays the contrast level configured for the display and allows adjustment of the display.</p> <p>Line 3: Current contrast value. Can be adjusted from 0 to 7.</p>	<p> Key held down or long touch: Increases contrast (maximum of 7).</p> <p> Key held down or long touch: Decreases contrast (minimum of 0).</p> <p>  Both keys held down: No action.</p>

SCREEN	MNEMONIC	INFORMATION	DESCRIPTION	KEYS FUNCTION
11. Log Status	 <p>Displayed for two seconds before accessing the "Log Status" screen.</p>	 <p>This screen will be updated whenever the current log status is changed.</p>	<p>Displays the current log status and allows them to be started and/or paused if the device is configured to allow keyboard start and/or end.</p> <p>En – Enabled logs.</p> <p>Dis – Disabled logs.</p>	 Key held down or long touch: Initiates logs if "By Keyboard" start mode is enabled.
				 Key held down or long touch: Pause records if the "By Keyboard" end mode is enabled.
				 Both keys held down: No action.
12. IP High	 <p>Displayed for two seconds before accessing the "IP High" screen.</p>	 <p>This screen will be updated whenever the IP is changed.</p>	<p>Displays the first two octets of the configured IP address.</p>	 Key held down or long touch: No action.
				 Key held down or long touch: No action.
				 Both keys held down: No action.
13. IP Low	 <p>Displayed for two seconds before accessing the "IP Low" screen.</p>	 <p>This screen will be updated whenever the IP is changed.</p>	<p>Displays the last two octets of the configured IP address.</p>	 Key held down or long touch: No action.
				 Key held down or long touch: No action.
				 Both keys held down: No action.

Navigation Keys

CONFIGURATION SOFTWARE

NXPERIENCE

The **NXperience** software is the main tool for configuring, and downloading data for **Accsense Ethernet Pro**. It allows for exploring all features and features of the device by communicating through its USB interface. It is also a complete tool for analyzing data logged by the **Accsense Ethernet Pro**.

NXperience allows for joint graphic analysis of multiple data, performing mathematical calculations, issuing reports, and exporting data to several formats and is a complete configuration tool for the new **NOVUS** device line.


This manual describes the software's generic features. For instructions about device configuration, refer to the specific operating manual. The software can be downloaded free of charge from our website www.dataloggerinc.com, in the Downloads area.

	<p>Each time the device receives a new configuration through NXperience, the data in the logs internal memory will be erased and, therefore, there will be no publication By MQTT until new data is logged.</p> <p>When a memory download is performed by NXperience, there will be a pause in the MQTT publication until the download is finished.</p>
--	---

CONFIGURING ACCSENSE ETHERNET PRO WITH NXPERIENCE

It is possible to configure **Accsense Ethernet Pro** by clicking the **Configure** button, located both on the **NXperience** (Windows) software home screen.

GENERAL PARAMETERS



INFORMATION

- **Device Tag:** Allows you to set a name, which will be used as channel identification during a download, for the digital channel. The field accepts up to 16 characters.
- **Serial Number:** Shows the device unique identification number.
- **Firmware Version:** Shows the firmware version recorded in the device.
- **Firmware Version of the Ethernet Module:** Shows the firmware version of the device's Ethernet module.
- **Model:** Displays the device model name.

DISPLAY

- **Active Display:** Allows you to configure when the display should become active.
 - **Always:** If configured, it will keep the display active, following the configured contrast and update range.
 - **By Keyboard:** If configured, the display will be activated whenever a key is pressed and will remain active for 1 minute (until a key is pressed again). This setting will follow the configured contrast.
 - **Never:** If configured, it will keep the display off.
- **Contrast:** Allows you to configure the display contrast level. There are eight levels of contrast. The lowest level simplifies viewing at the upper and lower viewing angles and the higher-level simplifies viewing at the front viewing angle.
- **Update Interval:** Allows you to configure how often the display information will be updated.
 - **Use log interval:** If configured, it will cause the display information to be updated at each log range.
 - **Interval:** Allows you to set a display update range in seconds that is smaller than the log range. This way, the input channels will be read and will update the display at this range. The minimum range is 1 second; the maximum range is 18 hours.

CLOCK

- **Date/Time:** Allows you to set the date/time used to set the device clock.
- **GMT:** Allows you to configure the GMT of the place where the device will be used (preferably during first use). By default, **Accsense Ethernet Pro** is set to GMT 0.
- **Date/Time Format:** Allows you to configure the clock format to 24 hours or AM/PM.

ANALOG CHANNELS PARAMETERS






Figure 14 – Analog Channel Screen

- **Tag:** Allows you to set a name, which will be used as channel identification during a download, for the digital channel. The field accepts up to 16 characters.
- **Input Type:** Allows you to configure the type of sensor to be used in each analog channel.
- **Unit:** Allows you to configure the unit for each analog channel. In the case of temperature sensors, it is possible to select the units °C or °F. For other sensors, it is possible to describe the unit with up to eight characters.
- **Mode:** Allows you to configure the operation mode to use for each analog channel. If "Instant" mode is selected, the channel is read, and the value will be logged at each log range. If "Average" mode is selected, the device will take 10 channel readings within the log range and at each log range the average of these 10 readings will be logged.
- **Decimal Places:** Allows you to configure the number of decimal places of each analog channel. Temperature Sensors can be configured to show up to one decimal place. Other sensor types can be configured to show up to two decimal places.
- **Lower Limit:** If the sensor configured for the channel is a temperature or internal diagnostic sensor, the lower limit will be filled by the software with the sensor's lower limit. If the sensor configured for the channel is of the linear sensor type (mV, V, or mA), it will be necessary to fill in the desired value to represent the minimum value of the chosen sensor.
- **Upper Limit:** If the sensor configured for the channel is a temperature or internal diagnostic sensor, the upper limit will be filled by the software with the sensor's upper limit. If the sensor configured for the channel is of the linear sensor type (mV, V, or mA), it will be necessary to fill in the desired value to represent the maximum value of the chosen sensor.
- **Offset:** Allows you to make small adjustments to the readings of each channel. The configured Offset will be added to all readings performed on the configured channel.




CUSTOM CALIBRATION

The  icon opens the custom calibration screen, which allows you to adjust up to 10 measurement points for each channel. When a custom calibration has been configured, the minimum number of setpoints is two points.



n°	Measured [°C]	Desired [°C]

Figure 15 – Customized Calibration Screen

- **Measured:** Displays the device's read value for which a correction is desired. It can be obtained by clicking the "Read Channel" button or manually filled in.
- **Desired:** Shows the user's desired value for the device measured value. It must be filled manually.
- **Read Channel:** Allows you to obtain the device's values during a custom calibration.
- **Add:** Allows you to enter the "Measured" and "Desired" pair in the Custom Calibration table.
- **Modify:** Allows you to modify the "Measured" and "Desired" pair in the Custom Calibration table.
- **Organize** : Allows you to sort the Custom Calibration table.
- **Delete** : Allows you to delete the selected line from the Custom Calibration table.
- **Delete All** : Allows you to clear the entire Custom Calibration table.
- **Apply:** Allows you to apply the custom calibration to the channel being configured.
- **Cancel:** Allows you to cancel the Custom Calibration operation.

DIGITAL CHANNEL PARAMETERS

"EVENT LOG" OR "LOGS CONTROL" MODE




Figure 16 – Digital Input Screen: Event Log Mode

- **Tag:** Allows you to set a name, which will be used as channel identification during a download, for the digital channel. The field accepts up to 16 characters.
- **Input Mode:** Allows you to select the digital input mode, which has the options "Pulse Count", "Event Log", or "Logs Control". If the "Logs Control" mode is selected, the "By Digital Input" mode must be selected in the "Start Mode" and "End Mode" parameters in the "Data Logs" screen. Otherwise, the configuration will have no effect.
- **Sensor Type:** Allows you to configure the sensor type to be connected to the digital input: PNP, NPN, or Dry Contact.
- **Event Edge:** Allows you to configure the desired event edge. This way, the device will log events whenever the configured edge is detected at the digital input. In the "Event Log" mode, you can configure so that the logs are made during the Rising, Falling, or Both edges. In the "Logs Control" mode, it is possible to select to control logs at the Rising, Falling, or Both edges, logging at logic level '1' or logical level '0'.
- **Debounce:** It will be necessary to configure a debounce time for edge detection. Debounce refers to the sensor stabilization time – the minimum time at which the sensor must remain at the logical level of interest so that the detected edge is considered valid. The minimum configurable debounce time is 50 milliseconds; the maximum are 6 seconds. The device will only register the event after the end of the debounce time.

CHANNELS GENERAL PARAMETERS




Figure 17 – Digital Input Screen: General Configuration

- **Alarm Buzzer Runtime:** Allows you to set the buzzer runtime for each time the device enters an alarm situation. The configuration will be performed in seconds, from 0 to 65000 s, where 0 means that the buzzer should not be triggered.
- **Mains Frequency:** Allows you to set the local power grid frequency (50 Hz or 60 Hz) for the device to perform better.
- **Intern Temperature:** Allows you to set the unit of measure in which the internal temperature will be displayed.
- **Digital Output Mode:** Allows you to configure the digital output mode, which can be configured as Disabled, Auxiliary Electronic Switch, or Alarm Status.
 - **Auxiliary Electronic Switch:** Allows you to control the power supply of external instruments during analog channel readings.
 - **Drive Time:** Allows you to configure, in seconds, how long before each acquisition the digital output must be triggered. The minimum configurable time is 0 seconds; the maximum time is 15 minutes (900 seconds). If equal to 0, the Auxiliary Electronic Switch will be enabled at the exact moment of an acquisition. If greater than or equal to the lowest acquisition range, the Auxiliary Electronic Switch will remain continuously enabled.
 - **Alarm Status:** In this mode, the digital output will follow the current and general alarm status. If any channel is in an alarm situation, the Digital Output will be enabled. If no channel is set to alarm, the Digital Output will be disabled.

LOG CONFIGURATION




Figure 18 – Log Screen

LOGS

- **Log Data:** Enables or disables the device data logging.
- **Log Interval:** Allows you to select the frequency, in seconds, with which an acquisition must be made and logged in the memory.
 - **Minimum Range:**
 - 1 second - if no channel is configured to operate on average
 - 10 seconds - if a channel is configured to operate on average
 - **Maximum Range:** 18 hours.

START MODE

- **Immediate Start:** Allows logs to be started shortly after the device is reconfigured.
- **Date/Time:** Allows you to set the date/time when the logs are to be started.
- **By Keyboard:** In a screen in the display, you can change the logs status to *enabled*, which start the logs (in case they had not been started yet).
- **By Digital Input:** Allows logs to be initiated from the digital input. This parameter is available if the digital input is enabled and configured in the "Logs Control" mode. This way, the logs will be started the moment the digital input is triggered. The log edge shall be configured in the digital input parameters.
- **By Software:** Allows logs to be started using an **NXperience** command.
- **Daily:** It allows the logs to be started every day and at the configured time. The "Daily" log start mode also requires "Daily" log end mode.
- **By Alarm:** Allows logs to be started from a specific alarm.

STOP MODE

- **Non-Stop:** Allows logs to continue indefinitely. When filling the memory, the oldest data will be deleted so that the most recent ones can be saved.
- **Date/Time:** Allows you to set the date/time when the logs are to be ended.
- **By Keyboard:** Allows you to change logs status to *disabled* on a screen in the display by instantly closing the logs.
- **By Digital Input:** Allows logs to be paused from the digital input. This parameter is available if the digital input is enabled and configured in the "Logs Control" mode. This way, the logs will be paused the moment the digital input is triggered. The log edge shall be configured in the digital input parameters.
- **By Software:** Allows logs to be ended using an **NXperience** command.
- **Daily:** It allows the logs to be ended every day and at the configured time. The "Daily" log start mode also requires "Daily" log end mode.
- **By Alarm:** Allows logs to be stopped from a specific alarm.

The combinations allowed for starting and ending logs are as follows:

START MODE	STOP MODE
Immediate	Non-Stop or Date/Time or Keyboard or Software or Alarm
Date/Time	Non-Stop or Date/Time or Keyboard or Software or Alarm
Digital Input	Non-Stop or Digital Input
Keyboard	Non-Stop or Keyboard
Software	Non-Stop or Software
Daily	Daily
Alarm	Non-Stop or Alarm

Table 3 – Logs End Modes

COMMUNICATION PARAMETERS

ETHERNET CONFIGURATION




Figure 19 – Configuration Screen

- **Obtaining Address:** Allows you to determine how **Accsense Ethernet Pro** will try to acquire an IP: DHCP (*Dynamic Host Configuration Protocol*), protocol that allows the device's IP (*Internet Protocol*) to be assigned by the network server, or Static, which allows the user to set the IP address, subnet mask, and default gateway for the connection. In this case, you can also set the DNS (*Domain Name System*).
- **IP Address:** Refers a device identification (computer, printer, etc.) on a local or public network. Each computer or device on the Internet or on an internal network has a unique IP. This is a required field when "Obtaining Address" is marked as "Static".
- **Subnet Mask:** Also known as *subnet mask* or *netmask*, it allows you to divide a specific network into smaller subnets, making it more effective to use a particular IP address space. This is a required field when "Obtaining Address" is marked as "Static".
- **Gateway Default:** Refers to the device address on the network that connects your computers to the internet. This is a required field when "Obtaining Address" is marked as "Static".
- **DNS Server:** Refers to a hierarchical and distributed name management system for computers, services, or any resource connected to the Internet or a private network. This is an optional field when "Obtaining Address" is marked as "Static".

SETTING UP ACCSENSE CLOUD CONNECTION PARAMETERS




Figure 20 – Configuration Screen: MQTT

- **Enable MQTT:** Enables or disables data submission by MQTT protocol. When the **Accsense Ethernet Pro** does not have an active external power supply and is running on batteries, the Ethernet interface will remain disabled and, therefore, sending data through this protocol as well.
- **Broker User:** Allows you to enter the registered user's login on the Broker. The field accepts up to 40 characters. If the field is empty, the connection will be made in anonymous mode.
- **Broker Password:** Allows you to enter the registered user's password on the Broker. The field accepts up to 40 characters. If the field is empty, the connection will be made in anonymous mode.
- **Broker URL or IP:** Allows you to enter the Broker address, which can be a URL (*Uniform Resource Locator*) or an IP. The field accepts up to 60 characters.
- **Time Format:** Allows you to choose the time format to display: DateTime or Unix Timestamp. Changes the sent date/time format of the JSON frame.
- **Boolean Format:** Indicates how Boolean variables will be displayed in the JSON frame. For more information, check the [Boolean Format](#) section of the [MQTT Protocol](#) chapter.
- **Clean Mode:** When enabled, it indicates to the Broker that it is necessary to store only the last data of each topic. By disabling this option, the Broker, if configured, will keep all historical data stored.
- **Write Permissions:** Selects which commands will be available for user writing via MQTT.
- **Publication Topic:** Allows you to view the subscription and publication topic formats.
- **Service Port:** Allows you to define the port number used to connect to the Broker.
- **QoS:** The "Quality of Service" parameter allows you to select the level of quality of service used to send MQTT messages. Your options are 0, 1, or 2. For more information, check the [QoS](#) section of the [MQTT Protocol](#) chapter.
- **JSON Format:** Changes the formatting of the JSON frame as required by the supervisor. For more information, check the [JSON Format](#) section of the [MQTT Protocol](#) chapter.

- **Security:** Allows you define the security protocol and data encryption to be used by the MQTT Broker.
 - **None:** None security measures will be used.
 - **TLS V1.2 – CA Only:** If this option is selected, the Broker will use the Transport Layer Security (TLS) 1.2 protocol, which requires a TLS certificate recognized by a certification authority (CA), to ensure the privacy and integrity of the data.
 - **TLS V1.2 – Self Signed:** If this option is selected, the Broker will use the Transport Layer Security (TLS) 1.2 protocol, which, in addition to the TLS certificate recognized by a certification authority (CA), also requires authentication of the client certificate and its private key to ensure privacy and integrity of the data.
- Note:** CA certificate, client certificate and private key files are accepted in .pem and .der formats only.

ALARM CONFIGURATION




Figure 21 – Alarms screen

- **Tag:** Allows you to set a name, which will be used as alarm identification, for each alarm enabled. The field allows up to 16 characters.
- **Operation:** Allows you to select the operation to be performed by the alarm enabled. This feature has three parameters, which allow you to select the channels or setpoint to be analyzed and the operation to be performed (see chapter [Alarms](#)).
 - **Setpoint:** Allows you to set the value to be exceeded for the channel to satisfy the alarm situation.
 - **Hysteresis:** Allows you to set the barrier to be exceeded for the channel to exit the alarm situation.
 - **Range:** Allows you to set the range that will satisfy the alarm situation.



When configuring the alarm for a digital input that is configured for "Event Log" or "Logs Control" mode, you can only use the '=' comparison with Setpoints '0' or '1', since the alarm will be used to compare with the logic level of the channel. Also, it is important to note that if configured for "Event Edge: Rise" or "Event Edge: Fall", the alarm may never enter or never leave the alarm state. Thus, for the alarm to operate correctly, it is recommended to use the "Event Edge: Both" option.

- **General:** Allows you to enable or disable the alarm delay option.
 - **Enable delay:** Allows you to enable the delay of configured alarms. Once enabled, the device will only consider an alarm if the setpoint is exceeded and maintained for a timer longer than the configured delay.
 - **Configure seconds:** Allows you to configure the delay period to be considered. Maximum value: 3600 seconds.




Figure 22 – Alarm actions

- **Alarm Actions:** Allows you to select the actions to be taken whenever the configured alarm enters an alarm situation.
 - **Send E-mail to:** Allows you to select the contacts that should receive this alarm notification (see [SMTP Protocol](#) section of the [Configuration Software](#) chapter).
 - **Activate Buzzer:** Allows you to select so that the buzzer is activated whenever the configured alarm goes into alarm.
 - **Start Logs:** If the Log Start Mode is set to "By Alarm", it allows you to start logging every time the alarm goes into alarm. The "Start Logs" and "Stop Logs" actions are mutually exclusive. Once an alarm has been set to start the logs whenever the device enters alarm situation, it will not be possible to use the same alarm to stop them.
 - **Stop Logs:** If Log Stop Mode is set to "By Alarm", it allows you to stop logging every time the alarm goes into alarm. The "Start Logs" and "Stop Logs" actions are mutually exclusive. Once an alarm has been set to stop the logs whenever the device enters alarm situation, it will not be possible to use the same alarm to start them.
 - **Log while Active:** If the Start Mode and Stop Mode are set to "By Alarm", it allows you to register whenever the configured alarm is set to alarm. If the configured alarm is no longer in alarm, the device will automatically stop logging. If an alarm has been set in the "Start Logs" or "Stop Logs" modes, it will not be possible to set any alarm in the "Log while Active" mode. Unlike the previous modes, which allow only a single alarm to be configured for each action, this mode has many alarms.

COMPARISON BETWEEN CHANNELS




Figure 23 – Comparison between channels

You can create a comparison alarm between two channels. When selecting the operation and channels to be compared, you can add an offset value (corresponding to the parameter highlighted in red) to the second selected channel. Thus, the value of the first channel will be compared to the value of the second channel and the configured offset value.

DIAGNOSTICS

It is possible to view the **Accsense Ethernet Pro** diagnostics tab by clicking the **Diagnostics** button located on the **NXperience** home screen. By clicking on it, the software will monitor some device states. The information update range is 1 second.

LOGS




Figure 24 – Diagnostics Screen: Logs

- **Log Status:** Displays information about the log status, such as the number of recorded logs, the available memory, the number of active channels, and the date of the first and last log in the **Accsense Ethernet Pro** memory.
- **Log Control:** Allows you to start or pause **Accsense Ethernet Pro** data logging. For this option to be active, the "By Software" parameter must be enabled in start and/or end of log mode.

CHANNELS




Figure 25 – Diagnostics Screen: Channels

- **Analog Channels and Digital Channel:** Displays information about the acquisitions made by the device on the analog channel sensors and on the digital channel sensor.
 - **Last Read Value:** Displays the value of the last acquisition performed by the device on the corresponding channel sensor. The displayed value may have been updated by a display update frequency and not logged in the memory.
 - **Minimum Read Value:** Displays the minimum read value by the device on the corresponding channel sensor. The displayed value may have been read by a display update frequency and not logged in the memory.
 - **Maximum Read Value:** Displays the maximum value read by the device on the corresponding channel sensor. The displayed value may have been read by a display update frequency and not logged in the memory.
 - **Last Accumulated Value:** For the digital channel, it displays the last accumulated value by the device in Pulse Count mode. Clicking on the **Reset** button allows resetting the accumulator value and restarting the counting.

ALARMS




Figure 26 – Diagnostics Screen: Alarms

This tab provides information on the history of enabled and configured alarms for **Accsense Ethernet Pro** (see [Alarms Configuration](#) section), its current condition, and a color legend that shows you if the configured alarms are currently in alarm, whether the configured alarm has already entered an alarm situation at some point, or whether the configured alarm has never entered an alarm situation.

COMMUNICATION




Figure 27 – Diagnostics Screen: Communication

- **Ethernet:** Displays information about the device's Ethernet connection.
 - **State:** Displays information about the device's current state.
 - **IP Address:** Displays information about the device's IP address.
 - **MAC Address:** Displays information about the device's MAC address.
 - **Mask:** Displays information about the device's mask.
 - **Gateway Default:** Displays information about the device's gateway default.
- **Protocols:** Displays information about the device's protocols
 - **Modbus TCP:** Informs you whether the Modbus-TCP protocol is enabled or disabled and the number of currently active connections.
 - **MQTT:** Informs you whether the MQTT protocol is enabled or disabled and, if enabled, provides data about the last time information was sent and its status.
 - **NOVUS Cloud:** Informs you whether the sharing feature with **NOVUS Cloud** is enabled or disabled, and if enabled, provides information about the last data submission to the cloud and its status.
 - **SMTP:** Informs you whether the SMTP protocol is enabled or disabled and, if enabled, provides information about the last scan performed and its status.
 - **Last Register:** Informs you the date and time of the last log made by the device.

MISCELLANEOUS




Figure 28 – Diagnostics Screen: Miscellaneous

- **Power:** Displays the device's power information.
 - **Power Supply:** Displays the current power supply of the device.
 - **Battery Level:** Displays the current battery level status. This information is updated in the logs frequency with a minimum frequency of 5 minutes.
 - **External Power Supply Voltage:** Displays the external power supply voltage of the device. This information is updated in the logs frequency with a minimum frequency of 5 minutes.

ACCSENSE CLOUD WEB SOFTWARE


CONNECTION TO ACCSENSE CLOUD PORTAL

USING A WEB BROWSER

To connect to the Accsense cloud to view live and historical data and alarms, open a web browser on your computer and go to:

<http://monitor.accsense.com>

and you will be presented with the login screen:



Enter your email and password to sign in. The sign in password is the one that you established in response to the original email to create your account. If you have forgotten your password, click the “Forgot your password?” link and enter your email in the following screen to receive an email to reset your password.

MOBILE APP

Alternatively, you can access the Accsense Cloud via our mobile app which is available for iOS or Android.

IOS

Go to the app store on your iPhone or iPad and search for the Accsense app or [click here](#)

ANDROID

Go to the Google Play Store and search for the Accsense app or [click here](#)

Enter your email and password to sign in.

Once you have successfully logged in, you will be presented with the main screen:





Figure 1 – Main Screen

ACCOUNTS PREFERENCES – DESKTOP ONLY

To access the User Preferences, click on the icon for your account in the upper right corner and select My Account to open the account settings window.



This window has 3 tabs, one for general settings, one for the visualization settings and one for the security settings.

GENERAL INFORMATION

The general information tab is only available on the web version of the application and not the mobile versions. It contains the settings for:


Email: The email address that is used for your login, for notifications and for password resets

Name: Your user name which is displayed for entries in the audit log

Phone: The phone number that is uses for SMS and voice notifications

Company: Your company name

Time zone: This is the value that is used to adjust the time for the data displays on the web site and for notifications.



The screenshot shows the 'Account Settings' page with the 'General information' tab selected. The page contains several input fields: 'E-mail' with a placeholder 'example@domain.com', 'Name' with a placeholder 'John Doe', 'Phone' with a placeholder '123 456 7890', 'Company' with a placeholder 'enter your company', and 'Time zone' with a dropdown menu showing '(GMT-04:00) New York'.

VISUALIZATION PREFERENCES


The visualization preferences tab is only available on the web version of the application and not the mobile versions. This window contains the settings for:

Language: English, French, Portugese or Spanish

Date Format: MM/DD/YYYY, DD/MM/YYYY or YYYY-MM-DD

Decimal Separator: “.” or “,”


Time Format: 12 or 24 hour



The screenshot shows the 'Account Settings' page with the 'Visualization Preferences' tab selected. The page contains several settings: 'Language' with a dropdown menu showing 'English (United States)', 'Dashboard' section with 'Show last updated at' set to 'Widget menu' and 'Decimal separator' set to 'Dot' (with 'Comma' also visible), 'Date format' set to 'MM/DD/YYYY', and 'Time format' set to '12-Hour' (with '24-Hour' also visible). Examples of the resulting formats are provided: 'E.g. 1,234.56' for the decimal separator and 'E.g. 10/15/2019 05:50 PM' for the time format.

SECURITY PREFERENCES

The security preferences tab is only available on the web version of the application and not the mobile versions. This screen allows you to change your password or delete your account.



USERS

Clicking the Users button in the list of items on the left of the screen will open the user settings window. The **Overview** tab will show the current list of users for your account:




Figure 2 – User Settings Overview

Use the **Create user** button in the upper right corner to add users to your organization. After clicking this button, a screen will pop up to enter the information for the new user:




Figure 3 – Creating A User

Name: Your user name which is displayed for entries in the audit log

Email: The email address that is used for your login, for notifications and for password resets

Phone: The phone number that is used for SMS and voice notifications

Access Type: Manager will have full access to modify settings and view data or End-User which can only view data and acknowledge alarms.

Click the **Create** button at the bottom to send the email invitation to the user to finish creation of their account.

On the main User List screen, there are 4 icons to the right of each user that allow you to change their account settings:


Click the **Pencil** icon to edit the user's information including name and phone number.

Click the **Padlock** icon to change the user's password.

Click the **Trash Can** icon to delete the user's account

Click the **Letter** icon to resend the email invitation.

The User Groups tab will show any groups that you have created to be used in custom lists.



Here we have created an “Admin” group to be used later on for notification of communications loss alarms.

The **Additional Contacts** tab is used to create other users that can receive notifications but who don't have a regular account to log into the systems. For example, you may want to have an IT person or service technician receive notifications for communications alarms or temperature alarms but which don't require regular access to the system.




Figure 4 – Creating Additional Contact

SENSOR SUMMARY

The sensor summary provides an overview of all of the information for the sensors currently configured for your account.




Figure 5 – Sensory Summary Window

ALARM LIST

The alarm list window shows all of the currently active or unacknowledged sensor related alarms for your devices. Clicking the **Pencil** icon under Controls column will pop up a screen to allow you to enter the corrective action text and acknowledge the alarm which sends it to the Audit history page.

Add Corrective Action ✕

Corrective Action

please enter the corrective action taken.

Cancel
Acknowledge


SENSOR LIST

The sensor list window shows the sensor measurement data including the sensor name, the last received value and the date and time that the data was received. The Alarm Status column shows the current state of the sensor. A red clock indicates that the sensor is currently in an alarm state, green means the readings are within range.

The list also has 4 clickable icons to view and configure the different sensor inputs:


History Column – **Graph** icon

Clicking the graph icon under the History column will switch the view to the data for that sensor which includes the current value, the minimum and maximum within the last 24 hours, a historical trend chart and a listing of historical data values. By clicking on the 3 dots in either the graph or data list, you can export the selected data to a file.



Alarms Column – **Clock** icon

Clicking the Clock Icon under the Alarms column brings up the alarm settings window.



Click the **Add New** button to create a new alarm. Click the **Pencil** icon in an existing alarm to change the settings:




Figure 6 – Creating/Editing Alarm Conditions

On the first page of the Alarm settings window, you can change the various alarm settings

Type of Alarm - whether it is for above or below a particular point

Alert Activation - whether the alarm alert is active or not

Recurring Alarm - If the notification will be once or if the notification will be sent with every measurement out of range

Consecutive Behaviors - How many readings in a row need to be out of range before the alarm is generated

Above/Below - The actual alarm set point value

Once these settings are complete, click the Continue button at the bottom to go to the second page to select the type of alarm notification(s) and recipient(s):





Figure 7 – Creating/Editing Alarm Notifications

The notification methods are self-explanatory. The Recipient(s) allow you to select from a list of contacts and or groups that are currently available within your account.

Settings Column – **Gear** icon

The sensor settings window allows you to configure custom calibration coefficients to apply to the raw measured data.



This window also displays any changes to the configuration of this sensor.

Controls - **Pencil** icon

Clicking the Pencil icon in the controls column allows you to change the name of the sensor that shows up on the various screens:



DEVICES

Click on **Devices** in the left column opens the Devices Overview Page.

The **Alarm List** window shows any communications alarms for the devices in your account. If the alarm is red it indicates that the alarm is currently active. Clicking the **Pencil** icon to the right of any alarm allows you to acknowledge the alarm and enter a corrective action.

Device Name	Alarm Type	Alarm Information	Alarm Time	Corrective Action	Controls
LogBox_Test1	Communication	Communication with the device has been restored.	03/13/2025 01:52:38 pm		[Edit]
LogBox_Test1	Communication	Communication with the device has been lost.	03/13/2025 11:52:03 am		[Edit]

The **Device List** window contains a list of all of the devices associated with this account.

Status	Name	Alarm Status	MQTT Toki	Serial Num	Analog Ch	Analog Ch	Analog Ch	Digital Ch	Last Input	Controls
	LogBox_Test1		6e21bf...	221561...	Temper...	Temper...	Humidity	None	04/21/2025 04:45:48 pm	[Edit] [Home] [Refresh]
	LogBox_Test2		342aef...		Temper...	None	Temper...	None	03/20/2025 10:46:48 am	[Edit] [Home] [Refresh]
	LogboxLTE		03054a...		Temper...	None	None	None	02/04/2025 07:53:48 am	[Edit] [Home] [Refresh]

The **Status** column shows if the device is currently receiving data or if it has been disabled.

The **Alarm Status** column has 3 possible states:

1. Gray the communication Alarm is disabled
2. Green the communication Alarm is enabled and the device is not in an alarm state
3. Red the communication Alarm is enabled and the device is in an alarm state

Click the **Edit Alarms** button to bring up the window to edit the communications alarms for the devices

Device List						
Name	Status	Time Interval	Recipients	Delivery Method	Controls	
LogboxLTE						
LogBox_Test2						
LogBox_Test1		15 Minutes	Terry TerryAol	Email SMS Voice Push		

Click the **Pencil** icon the **Control** column of the alarm settings window to change the communications alarm settings for any of the devices:

Edit Device ✕

Time Interval *

Recipients *

Terry
TerryAol
✕

Delivery Method *

Email
SMS
Voice
Push
✕

Cancel
Confirm

On this screen you can change:

The **Time Interval** for the period of communications loss before the alarm is generated

The **Recipients** of the communications loss alarm. This can be any users or groups configured for your account.

The **Delivery Method** for alarm loss notification, email, SMS, voice and/or push notification

When these settings are complete, click the **Confirm** button at the bottom of the Alarm Settings window to save the new communication alarm settings and return to the Device List page.

There are several other settings in the **Controls** column of the Device List:

The Pencil icon allows you to change the name of the device and type of measurement for each channel of the device.

The 2 **Hand** icons are used to enable and disable receiving data from the device.

AUDIT LOG

By clicking on the **Audit Log** button, you can open the view of all of the system log entries:




Figure 8 – Audit Log Window

By default, it opens to the **All Logs** view. There are 4 tabs at the top to open individual views of each log file.

NOTIFICATION LOG

The notification log contains a list of the different messages (Email, SMS, Voice and/or Push) that have been sent in response to a communications loss or reconnect event along with the recipient, the date and time the message was acknowledged, and the date and time the message was sent.

User Name	Notification Type	User Acknowledgement	Date and Time Acknowledged	Date and Time Sent
Terry	Email	Passive	21/04/2025 03:00:05 PM	04/21/2025 03:00:05 pm
TerryGmail	Email	Passive	21/04/2025 03:00:05 PM	04/21/2025 03:00:05 pm
Terry	Push			04/21/2025 03:00:05 pm
Terry	Voice			04/21/2025 03:00:04 pm
TerryGmail	Voice			04/21/2025 03:00:04 pm
Terry	SMS			04/21/2025 03:00:04 pm
TerryGmail	SMS			04/21/2025 03:00:04 pm
Terry	Email	Passive	21/04/2025 02:20:16 PM	04/21/2025 02:20:16 pm
TerryGmail	Email	Passive	21/04/2025 02:20:16 PM	04/21/2025 02:20:16 pm
Terry	Push			04/21/2025 02:20:16 pm
Terry	Voice			04/21/2025 02:20:15 pm
TerryGmail	Voice			04/21/2025 02:20:15 pm
Terry	SMS			04/21/2025 02:20:15 pm
TerryGmail	SMS			04/21/2025 02:20:14 pm
Terry	Email	Passive	21/04/2025 02:09:48 PM	04/21/2025 02:09:48 pm
TerryGmail	Email	Passive	21/04/2025 02:09:48 PM	04/21/2025 02:09:48 pm

The magnifying glass will allow you to search for specific events and clicking on the 3 dots will allow you to export the data.

ALARM LOG

The alarm log contains a list of the different messages, Email, SMS, Voice and/or Push that have been sent in response to alarm event along with the sensor name and value that generated the alarm, the date and time the message was sent, the date and time the message was acknowledged and the corrective action that was entered.

Sensor Name	Alarm Type	Alarm Information	Acknowledged by	Corrective Action	Date and Time	Date and Time Triggered
Vaccine1	Temperature	Variable: 'temperature' is > 30, current value: 30.7	TagoIO Admin		13/01/2025 ...	01/10/2025 02:52:42 pm
Vaccine1	Temperature	Variable: 'temperature' is > 30, current value: 30.7	Terry		14/01/2025 ...	01/13/2025 12:02:32 pm
Vaccine1	Temperature	Variable: 'temperature' is > 30, current value: 30.7	TagoIO Admin		14/01/2025 ...	01/14/2025 08:37:29 am
Vaccine1	Temperature	Variable: 'temperature' is > 30, current value: 30.9	TagoIO Admin		14/01/2025 ...	01/14/2025 11:47:27 am
Vaccine1	Temperature	Variable: 'temperature' is > 30, current value: 30.3	TagoIO Admin		15/01/2025 ...	01/14/2025 04:07:29 pm
Vaccine1	Temperature	Variable: 'temperature' is > 31, current value: 31.7	TagoIO Admin		16/01/2025 ...	01/16/2025 01:32:21 pm
Mikes office	Temperature	Variable: 'temperature' is > 90, current value: 200	TagoIO Admin		17/01/2025 ...	01/17/2025 03:05:38 pm
Mikes office	Temperature	Variable: 'temperature' is > 5, current value: 200	TagoIO Admin		17/01/2025 ...	01/17/2025 03:30:54 pm
Mikes office	Temperature	Variable: 'temperature' is > 5, current value: 200	TagoIO Admin		17/01/2025 ...	01/17/2025 03:30:54 pm
Vaccine1	Temperature	Variable: 'temperature' is > 31, current value: 32	TagoIO Admin	close the do...	03/02/2025 ...	01/20/2025 08:13:19 am
Vaccine1	Temperature	Variable: 'temperature' is > 30, current value: 31.7	TagoIO Admin	close the do...	06/02/2025 ...	02/06/2025 09:09:03 am
Vaccine1	Temperature	Variable: 'temperature' is > 30, current value: 32.6	TagoIO Admin	closea the d...	25/02/2025 ...	02/25/2025 01:40:36 pm
Vaccine1	Temperature	Variable: 'temperature' is > 30, current value: 31.4	TagoIO Admin	assada	26/02/2025 ...	02/26/2025 11:25:32 am
Vaccine1	Temperature	Variable: 'temperature' is > 30, current value: 31.3	TagoIO Admin	clasa da door	24/03/2025 ...	02/26/2025 02:30:30 pm
Vaccine1	Temperature	Variable: 'temperature' is > 30, current value: 30.4	Terry	close the do...	22/04/2025 ...	04/21/2025 03:00:05 pm

The magnifying glass will allow you to search for specific events and clicking on the 3 dots will allow you to export the data.

USER LOG

The user log contains a list of the changes to any of the user accounts within your organization .

Audit Log

All Logs Notification Log Alarm Log User Log Configuration Log

User Log

User Name	Affected User	Action	Date and Time
admin	User One	remove	06/04/2025 09:54:20 am
admin	User One	create	06/03/2025 03:04:31 pm
admin	User One	remove	06/03/2025 12:30:45 pm
admin	User One	create	06/03/2025 12:30:31 pm
admin	log	create	05/20/2025 03:58:10 pm
admin	log	edit	05/13/2025 10:02:34 am
admin	log	edit	05/13/2025 10:02:30 am
admin	John Smith	edit	05/13/2025 10:02:27 am
admin	Jane Doe	edit	05/13/2025 10:02:23 am
admin	Jane Doe	create	04/22/2025 04:17:36 pm
admin	John Smith	create	04/22/2025 04:17:05 pm
admin	log	create	04/21/2025 01:58:16 pm
admin	log	remove	03/20/2025 11:31:25 am
admin	log	create	03/20/2025 11:29:33 am
admin	log	remove	01/15/2025 10:01:16 am
admin	log	remove	01/15/2025 10:01:09 am

29 Actions

The magnifying glass will allow you to search for specific events and clicking on the 3 dots will allow you to export the data.

CONFIGURATION LOG

The configuration log contains a list of the changes to configuration of any of the sensors and alarms for your organization .

Audit Log

All Logs Notification Log Alarm Log User Log Configuration Log

Configuration Log

User Name	Affected Sensor	Action	Date and Time
TagpIO Admin	Vaccine1	Modified Alert	03/24/2025 04:29:37 pm
TagpIO Admin	Vaccine1	Modified Alert	02/06/2025 09:02:13 am
TagpIO Admin	Vaccine1	Modified Alert	02/06/2025 09:01:46 am

The magnifying glass will allow you to search for specific events and clicking on the 3 dots will allow you to export the data.

APPENDIX A - TROUBLESHOOTING

START/STOP MODES

Depending on the Start/Stop rule with which the device is configured, it may lose information if it is to continue registering during a power outage.

- **Start/Stop by Keyboard:** A Modbus command or digital input may be lost during the device's power-up.
- **Immediate Start:** "Date/Time" or "Daily" parameters will return when the device is powered up again and is able to resume the clock.

CLOCK

After a power failure, the **Accsense Ethernet Pro** cannot reset the clock on its own. Therefore, if the internal battery is discharged or missing and the clock information is lost, the device will not log until it is reconfigured.

After the clock is reset, data logging will automatically resume if the end mode meets the following conditions:

- **Non-Stop** or
- **Date/Time** (if it satisfies the parameters set according to the new clock setting) or
- **Daily** (according to the time configured).

In case of a power failure, the **Accsense Ethernet Pro** also does not retain the last value of the Accumulator Pulse Count. Therefore, when initializing the device after the clock is lost, the **Accsense Ethernet Pro** will assume as the value of the Accumulator Pulse Count the data present in the last register.

ALARM INFORMATION

Alarm information, maximum and minimum values reached in each channel, as well as Date/Time of the last event are data that can be lost if the device is left out of power for more than 30 minutes. The data logged in the periodicity of logs or the digital input events, if it is configured for Event Log, are the only ones that are certainly not lost (unless a new configuration is applied, or the user chooses to clear the memory).

NXperience has the functionality of reporting the maximum and minimum values logged, as well as informing all logs in an alarm situation.

ANALOG INPUTS

- When a device that is connected to the mains (a thermocouple or voltage simulator, for example) is used in the analog inputs and is not isolated, it is recommended to use a different reading interface than USB. In some cases, due to the influence of the USB cable connection (probably by ground loops), the occurrence of noise and reading Offsets have been detected.
- When operated by batteries and no acquisition is being performed, **Accsense Ethernet Pro** will keep the analog circuit switched off. This strategy is necessary so that it can operate for more than two years without needing to change batteries. However, some analog signal simulators (thermocouple simulator or Pt100, for example) may not be able to operate correctly with this characteristic, causing false Offsets and oscillations in the readings. If such a problem is identified, it is recommended to power the **Accsense Ethernet Pro** by external power supply or By USB port while using the simulator.

- Setting the local network frequency (50 Hz or 60 Hz) is important to improve the analog channels' reading performance, even if the device is running on battery power. Usually, the power grid causes interference, which can be more easily mitigated if its frequency is known on the signal read by the sensors.

UNREGISTERED ALARMS

The alarm status information, as well as the maximum and minimum values reached in each channel, is updated by any events that trigger an acquisition, which may be a read in the log range or in the display update range. If a channel reaches a minimum or maximum value or an alarm condition during an acquisition that does not occur during the log range, it may not be logged in the memory. Thus, statuses may indicate that the channel has already reached one of these situations and the information is not available in a download.

The log range must be configured according to the maximum period allowed by the process being monitored, so that no important information is lost (and no longer being logged).

COMMUNICATION LINK LOSS

If there is a loss of the communication link between the Broker and any of the Subscribers or the possible lack of electricity, it is possible that Subscriber will lose some of the logs subsequently published by **Accsense Ethernet Pro**. If this occurs, the `set_download` topic allows you to request that the device resend the logs that were lost during that period, by setting a start date for it (see [Inscription Topic](#) section of the [MQTT Protocol](#) chapter).

PROBLEMS COMMUNICATING WITH THE DEVICE VIA USB INTERFACE

If you have problems communicating the device via the USB interface, it is recommended to perform the following procedure to speed communication and minimize incompatibility issues:

- a. Open the Device Manager:




Figure 1 – Device Manager

b. Open the COM port setting of the device:




Figure 2 – Device Manager

c. Open advanced COM port configuration options:




Figure 3 – Port settings configuration

d. Uncheck the Use FIFO buffers option:




Figure 4 – Advanced settings

PROBLEMS DURING FIRMWARE UPDATE VIA USB INTERFACE

If there are problems during the firmware update, it is recommended to perform the following procedure:

Before upgrading the firmware, verify if the latest version of **NXperience** has been installed.

If a failure occurs during firmware update, the following message will be displayed:




Figure 5 – Firmware failure

Click **OK** and verify if the device is still available for the update. If it is, click on **Program** again:




Figure 6 – Firmware update

If **NXperience** has been closed and/or it is no longer possible to find the device on the update screen, it is necessary to close the **NXperience**, turn off the **Accsense Ethernet Pro** and reconnect the device to the USB interface for a new attempt.




Figure 7 – Firmware failure

If the **NXperience** shows an error while reading the configuration, as shown in the figure below, and the device display is off, try the procedure described in the following step.




Figure 8 – Error reading configuration

On the **NXperience** startup screen, pressing the Ctrl + Shift + F12 keys simultaneously will cause the firmware update screen to reappear, as shown in **Fig. 8**.




Figure 9 – NXperience home screen




Figure 10 – Firmware update

Try to update the firmware again. If you cannot find the device, turn off the **Accsense Ethernet Pro** and switch it back on by holding down both keys. After that, repeat this procedure. In case of failure during previous procedures, contact **NOVUS** technical support.

APPENDIX B – UPDATING FIRMWARE

Accsense Ethernet Pro has two pieces of firmware: 1 located on the motherboard, which must be updated via USB, and 1 located on the Ethernet module, which must be updated by Over the Air technology. In a firmware update, it is important to update both. To do so, make sure you get the correct firmware versions from the **NOVUS** website and update the motherboard and the Ethernet module.

FIRMWARE UPDATE VIA USB

You can update the device firmware using the **NXperience** software. On the home screen, simultaneously press the Ctrl + Shift + F12 keys. A firmware update screen will appear:




Figure 1 – Firmware update

Once this is done, select the device to be updated, add the firmware file to be used and click the **Program** button.

OVER THE AIR (OTA) FIRMWARE UPDATE

The **Accsense Ethernet Pro** module can be upgraded using Over the Air (OTA) technology.

To perform this procedure, you must know the device's IP. After that, you will need to access it through a Browser. In the address bar, you must enter "the device's IP address: /ethernet_pro/upgrade " for example 192.168.88.86/ethernet_pro/upgrade.

Once the Browser loads the device firmware update page, you will need to upload a .bin file, which contains the Ethernet module new firmware version.

The firmware update through this interface has the objective of updating network services such as MQTT, Modbus-TCP, among others.




Figure 2 – Firmware update

APPENDIX C - TECHNICAL SPECIFICATIONS

FEATURES	ACCSENSE ETHERNET PRO	
Input Channels	3 analog inputs 1 digital input	
Compatible Analog Signals	Thermocouple J, K, T, N, E, R, S and B, Pt100, 0-50 mV, 0-5 V, 0-10 V, 0-20 mA, 4-20 mA	
Internal Measurements	Internal Temperature (NTC) Battery Voltage External Power Supply Source Voltage	
Analog Channels Input Impedance	Thermocouples / Pt100 / mV: > 2 M Ω mA: 15 Ω + 1.5 V V: 1 M Ω	
Pt100	Maximum cable offset resistance: 25 Ω Excitation Current: 166 μ A Used Curve: $\alpha = 0.00385$	
Digital Input	Logical Levels	Logical Level "0": from 0 to 0.5 VDC Logical Level "1": from 3 to 30 VDC
	Maximum Voltage	30 VDC
	Input Impedance	270 k Ω
	Input Current @ 30 VDC (typical)	150 μ A
	Maximum Frequency (squared wave)	Dry Contact: 10 Hz PNP: 2 kHz NPN: 2 kHz
	Minimum Pulse Duration	Dry Contact: 50 ms PNP: 250 μ s NPN: 250 μ s
Digital Output	1 PNP-type output Maximum current that can be switched at the output: 200 mA	
Display	3 lines, 4½ digits	
Resolution	Analog Signals: 15 bits (32768 levels) Digital Signal: 16 bits (65536 levels) Digital Signal (Accumulator): 32 bits (4294967296 levels)	
Memory Capacity	140000 logs (total)	
Log Range	1 second to 18 hours	

FEATURES	ACCSENSE ETHERNET PRO	
Log Type	Instant or Medium	
Log Trigger	Date/Time, Start button, digital input, software command or alarm	
Alarms	10 available alarms	
Internal Buzzer	Yes, it can be used for alarms	
Communication Interfaces	USB Interface IEEE 802.3u 10/100Mb with RJ-45 connector	
Software and App	NXperience (By USB or by TCP/IP network for desktops and notebooks)	
Power supply	Power Supply Source	Voltage: 10 VDC to 30 VDC Maximum Consumption: 300 mA Typical Consumption: 20 mA
	Power over Ethernet (POE)	Voltage: 40 VDC to 57 VDC Maximum Current: 100 mA Maximum Power: 3 watts
	Batteries	Internal rechargeable battery (Ethernet interface disabled)
Estimated Battery Life	80 hours of operation	
Operation Temperature	Using external power supply: -20 to 70 °C * Using POE	
Housing	ABS+PC	
Protection Index	IP40	
Dimensions	120 x 100 x 40 mm	
Certifications	CE, UKCA, FCC, CAN ICES-3 (A) / NMB-3 (A), ANATEL (07034-17-07089)	

Table 4 – Technical specifications

* Be careful with the operating temperature of the batteries. Extremely high or low temperatures can cause ruptures and leaks and cause damage to the device.

SENSORS RANGE AND ACCURACY

	Sensor	Sensor Minimum Value	Sensor Maximum Value	Sensor Resolution	Accuracy (%)
Thermocouples	J	-100.0 °C -148.0 °F	760.0 °C 1400.0 °F	0.1 °C 0.2 °F	0.15 % (F. E.) ± 0.5 °C ± 0.9 °F
	K	-150.0 °C -238.0 °F	1370.0 °C 2498.0 °F	0.1 °C 0.2 °F	0.15 % (F. E.) ± 0.5 °C ± 0.9 °F

	Sensor	Sensor Minimum Value	Sensor Maximum Value	Sensor Resolution	Accuracy (%)
	T	-160.0 °C -256.0 °F	400.0 °C 752.0 °F	0.1 °C 0.2 °F	0.15 % (F. E.) ± 0.5 °C ± 0.9 °F
	N	-270.0 °C -454.0 °F	1300.0 °C 2372.0 °F	0.1 °C 0.2 °F	0.15 % (F. E.) ± 0.5 °C ± 0.9 °F
	E	-90.0 °C -130 °F	720.0 °C 1328.0 °F	0.1 °C 0.2 °F	0.15 % (F. E.) ± 0.5 °C ± 0.9 °F
	R	-50.0 °C -58.0 °F	1760.0 °C 3200.0 °F	0.3 °C 0.5 °F	0.15 % (F. E.) ± 0.5 °C ± 0.9 °F
	S	-50.0 °C -58.0 °F	1760.0 °C 3200.0 °F	0.4 °C 0.7 °F	0.15 % (F. E.) ± 0.5 °C ± 0.9 °F
	B	500.0 °C 932.0 °F	1800.0 °C 3272.0 °F	0.4 °C 0.7 °F	0.15 % (F. E.) ± 0.5 °C ± 0.9 °F
Pt100	Pt100	-200.0 °C -328.0 °F	650.0 °C 1202.0 °F	0.1 °C 0.2 °F	0.15 % (F. E.)
Linear	0 to 50 mV	0.000	50.000	0.003 mV	0.15 % (F. E.)
	0 to 5 V	0.000	5.000	0.6 mV	0.15 % (F. E.)
	0 to 10 V	0.000	10.000	0.6 mV	0.15 % (F. E.)
	0 to 20 mA	0.000	20.000	0.001 mA	0.15 % (F. E.)
	4 to 20 mA	4.000	20.000	0.001 mA	0.15 % (F. E.)
Digital Input	Count Mode	0	65535		0.01 % (F. E.)
Internal Sensors	Temperature (NTC)	-40 °C -40 °F	125.0 °C 257.0 °F	0.1 °C 0.1 °F	0.15 % (F. E.) ± 0.5 °C ± 0.9 °F
	Battery Voltage	3.6	6.5	0.01 V	2 % (F. E.)

	Sensor	Sensor Minimum Value	Sensor Maximum Value	Sensor Resolution	Accuracy (%)
	External Power Supply Voltage	10.00	30.00	0.01 V	2 % (F. E.)

* F. E. = Full Scale = Span

Table 5 – Sensors range and accuracy

Accuracy: The sensor accuracy reading is measured in relation to the Full Scale and is proportional to the maximum measuring range of each sensor. For a Pt100 sensor, for example, which the **Accsense Ethernet Pro** can read in the range of -200 °C to 650 °C, with a precision of 0.15%, the accuracy in °C will be $(650\text{ °C} - (-200\text{ °C})) * 0.15\% = 1.28\text{ °C}$.

Thermocouples: The analog input circuit for the **Accsense Ethernet Pro** guarantees the accuracy specified in the Thermocouple sensors reading with a maximum cable impedance of 100 Ω. Thermocouple sensors with impedance above 100 Ω are read by **Accsense Ethernet Pro**. Accuracy, however, is not guaranteed. For reading the thermocouple sensors, the **Accsense Ethernet Pro** uses the internal temperature sensor for Cold Joint compensation (NTC). Just as with the internal temperature sensor, thermocouples may present a greater error than specified when there are sudden variations in ambient temperature. The specified accuracy is only guaranteed when the device is installed in an environment with a stable temperature for a time greater than one hour.

Pt100: The **Accsense Ethernet Pro** analog input circuit guarantees the accuracy specified in the reading of PT100 type sensors with a maximum cable resistance of up to 25 Ω. The device can read sensors with cables that have resistance above 25 Ω. In these cases, the accuracy and measurement range are not guaranteed. The **Accsense Ethernet Pro** performs the cable resistance compensation internally, if it is the same in the three wires that connect the device to the sensor.

Linear 0 to 50 mV: The analog input circuit of the **Accsense Ethernet Pro** guarantees the specified accuracy when reading electrical quantities of voltage type 0 to 50 mV with a maximum cable impedance of up to 100 Ω. Voltage sources with series impedance above 100 Ω can be read by **Accsense Ethernet Pro**. Accuracy, however, is not guaranteed.

Linear 0 to 5 V and 0 to 10 V: The analog input circuit of the **Accsense Ethernet Pro** guarantees the specified accuracy when reading electrical quantities of voltage type 0 to 5 V and 0 to 10 V with a maximum cable impedance of up to 200 Ω. Voltage sources with series impedance above 200 Ω can be read by **Accsense Ethernet Pro**. Accuracy, however, is not guaranteed.

Linear 0 to 20 mA and 4 to 20 mA: All **Accsense Ethernet Pro** input channels have common ground with each other as well as with the power supply source. Thus, for the **Accsense Ethernet Pro** to be able to correctly measure the current transmitters, it is necessary that they are fed by isolated sources or by using all current transmitters with the interconnected ground.

Digital Input: All **Accsense Ethernet Pro** input channels have common ground with each other as well as with the power supply source. For the **Accsense Ethernet Pro** to correctly measure the Digital Input sensor, such characteristic must be considered. For the logic levels of the sensor connected to the digital input to be correctly detected, it is recommended that the maximum series impedance with the sensor is less than 10 kΩ.

Internal Temperature Sensor: The **Accsense Ethernet Pro** has an internal temperature sensor of the NTC type that can be used for monitoring the ambient temperature. This sensor is used for the Thermocouples Cold Joint compensation. Because it is located inside the device's casing, it may present a greater error than specified when there are abrupt variations in ambient temperature. The specified accuracy is only guaranteed when the device is installed in an environment with a stable temperature for a time greater than one hour. The sensor allows readings in a range of -40 °C to 125 °C. The temperature, however, is limited to the device's operating range.

ETHERNET CONNECTIVITY

Accsense Ethernet Pro has an onboard module for communicating with 10/100 Mb Ethernet networks.

FEATURES	DESCRIPTION
Ethernet Standards	IEEE 802.3u 10/100Mb, RJ-45 connector

Table 6 – Ethernet standards supported by **Accsense Ethernet Pro**

APPENDIX D - CERTIFICATIONS

FCC

Contains FCC ID: N7NHL8549G

This device has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the device is operated in a commercial environment. This device generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, it may cause harmful interference to radio communications.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this device.

RF Exposure: To satisfy FCC RF exposure requirements, a separation distance of 20 cm or more should be maintained between the antenna of this device and persons during operation. To ensure compliance, operations at closer distances than this are not recommended. This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

IC

Contains IC: 21571-AVTEG001

This device complies with Industry Canada's license exempt RSS standard(s). Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

The installation of the transmitter must ensure that the antenna has a separation distance of at least 20 cm from all persons or compliance must be demonstrated according to the ISED SAR procedure.

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotopically radiated power (EIRP) is not more than that necessary for successful communication.

CE Mark / UKCA

This is a Class A device. In a domestic environment, it may cause radio interference and require the user to take proper measures.

ANATEL

This device is homologated by ANATEL, in accordance with the procedures regulated by Resolution 242/2000, and meets the technical requirements applied.

This equipment is not subject to the protection from harmful interference and may not cause interference with duly authorized systems.

For more information, see the ANATEL website: www.gov.br/anatel/pt-br.

NORM CISPR 22

This product is not suitable for use in domestic environments as it may cause electromagnetic interference. Otherwise, the user will be required to take whatever measures are necessary to minimize such electromagnetic interference.

APPENDIX E - WARRANTY

CAS Dataloggers LLC., warrants the instruments it manufactures against defects in either the materials or the workmanship for a period of one year from the date of delivery to the original customer. This warranty is limited to the replacement or repair of such defects, without charge, when the instrument is returned to CAS Dataloggers. This warranty excludes all other warranties, either express or implied, and is limited to a value not exceeding the purchase price of the instrument.

CAS Dataloggers LLC. shall not be liable for any incidental or consequential loss or damages resulting from the use of the instrument, or for damage to the instrument resulting from accident, abuse, improper implementation, lack of reasonable care, or loss of parts.

Where CAS Dataloggers LLC. supplies to the customer equipment or items manufactured by a third party, then the warranty provided by the third party manufacturer remains.